

DIAGRAMA ESQUEMÁTICO DE DISTRIBUCIÓN DE NODO LISP-164

TRONCAL 1 SAN MARTÍN DE PORRES - RED FTTH

SITE_SMP_C


DIRECCION
COORDENADAS
x=-77.06355083559869
Y=-12.030483590723847

240.0 m
144F


DIST: 100 m
HUB-1
Poste 7m SC-9
DIRECCION: None
COORDENADAS
X=-77.062466542271400
Y=-12.031557980662500

884 m
96F(1-8)

810 m
96F(1-8)


Dist
LISP-164 MD-02
96F-SM / SPLITTER 1 AL 4
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m 1067011-9
DIRECCION: None
COORDENADAS
X=-77.056252000000000
Y=-12.031943000000000


Dist
LISP-164 MD-01
96F-SM / SPLITTER 1 AL 4
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 8m SC-9
DIRECCION: None
COORDENADAS
X=-77.056793877054700
Y=-12.032057615210800

73 m
24F(1-2)

77 m
24F(1-2)

115 m
24F(1-2)

107 m
24F(1-2)


NAP-13 LISP-164 MD-02
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 8m SC-9
DIRECCION: None
COORDENADAS
X=-77.056753094688700
Y=-12.032164293127600


NAP-10 LISP-164 MD-02
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m SC-9
DIRECCION: None
COORDENADAS
X=-77.056296667539200
Y=-12.032249088729600


NAP-14 LISP-164 MD-02
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 8m SC-9
DIRECCION: None
COORDENADAS
X=-77.057068000000000
Y=-12.031953000000000


NAP-01 LISP-164 MD-01
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 8m 172086-9
DIRECCION: None
COORDENADAS
X=-77.056683306238600
Y=-12.031958198468100

96 m
24F(1-2)

111 m
24F(1-2)

81 m
24F(1-2)

115 m
24F(1-2)


NAP-08 LISP-164 MD-01
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 8m SC-9
DIRECCION: None
COORDENADAS
X=-77.056753094688700
Y=-12.032164293127600


NAP-11 LISP-164 MD-02
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m SC-9
DIRECCION: None
COORDENADAS
X=-77.056027674543800
Y=-12.032350307818700


NAP-06 LISP-164 MD-01
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 8m SC-9
DIRECCION: None
COORDENADAS
X=-77.057327000000000
Y=-12.031867000000000


NAP-02 LISP-164 MD-01
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m 172087-9
DIRECCION: None
COORDENADAS
X=-77.05696557988400
Y=-12.031757809000000

126 m
24F(1-2)

119 m
24F(1-2)

94 m
24F(1-2)


NAP-09 LISP-164 MD-02
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m SD-7
DIRECCION: None
COORDENADAS
X=-77.056783000000000
Y=-12.032238000000000


NAP-12 LISP-164 MD-01
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m SC-9
DIRECCION: None
COORDENADAS
X=-77.055895000000000
Y=-12.032403000000000


NAP-16 LISP-164 MD-02
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 7m SC-9
DIRECCION: None
COORDENADAS
X=-77.05696557988400
Y=-12.031471091175600

115 m
24F(1-2)


NAP-04 LISP-164 MD-01
24F-SM / SANGRAR
HILOS:
(01P05P SPL 1-2)
(02P06P SPL 3-4)
(03P07P SPL 5-6)
(04P08P SPL 7-8)
Poste 9m SD-7
DIRECCION: None
COORDENADAS
X=-77.057294088159000
Y=-12.031342406908000